



DROP DOWN DRILLING PLANS WITH KIMANA HINGE



▲ Overcrossing 90° door opening angle, it negatively effects the Kimana hinges.

Cabinet (X)		Door (Y)		L1
16 mm	4 mm	16 mm	2 mm	129
16 mm	4 mm	19 mm	_	131
18 mm	2 mm	18 mm	4	129
19 mm	-	16 mm	2 mm	125
19 mm	-	19 mm	-	127
20 mm	-	20 mm	-	127


For Kimana and adapter details refer to section "HINGES".



For other drilling plans and details please refer to the brochure.



DROP DOWN DRILLING PLANS WITH KIMANA HINGE






Overcrossing 90° door opening angle, it negatively effects the Kimana hinges.

Cabinet (X)		Door (Y)		L1
16 mm	4 mm	16 mm	2 mm	208
16 mm	4 mm	19 mm	-	210
18 mm	2 mm	18 mm	-	208
19 mm	580	16 mm	2 mm	204
19 mm	-	19 mm	25	206
20 mm	-	20 mm	<u> </u>	206


For Kimana and adapter details refer to section "HINGES".



For other drilling plans and details please refer to the brochure.




DROP DOWN DRILLING PLANS WITH KIMANA HINGE



Overcrossing 90° door opening angle, it negatively effects the Kimana hinges.

Cabinet (X)		Door (Y)		L1
16 mm	4 mm	16 mm	2 mm	314
16 mm	4 mm	19 mm	-	316
18 mm	2 mm	18 mm		314
19 mm	-	16 mm	2 mm	310
19 mm	-	19 mm	-	312
20 mm	180	20 mm	-	312





For other drilling plans and details please refer to the brochure.